



07 72 00

TRA SNOW & SUN

ROOF ACCESSORY SYSTEMS

TILE SEAL



APPLICATION STEPS

General Information

TileSeal™ should overlap 2 inches. Roof tile must be clean and dry. Air temperature should be at least 40°F.



STEP 1

Center TileSeal™ on top of roof nailing board. Staple or nail the TileSeal™ every 12 inches down hip or ridge nailing board.



STEP 2

Form the TileSeal™ to the tile roof surface. Install the TileSeal™ from the top of the hip to the eave.



STEP 3

Remove protective strip from adhesive tape.



STEP 4

Press TileSeal™ in pans of each tile. TileSeal™ can elongate 30% from barrel to pan. Take care that the edge area of the TileSeal™ is thoroughly pressed to tile. The corrugation of the TileSeal™ should become flat as the material is pressed into the tile. Then use a required rubber roller for adhesion.



STEP 5

Cut off the excess amount of the TileSeal™ at the end of the hip or ridge with a knife or sheet metal shears. The excess material can be used on the next project.



The perforations and edge of TileSeal™ are extremely sharp. Please wear gloves to eliminate the possibility of cuts and scrapes.

1657 South 580 East
American Fork, UT 84003



07 72 00

TRA SNOW & SUN

ROOF ACCESSORY SYSTEMS

TILE SEAL



APPLICATION STEPS

General Information

TileSeal™ should overlap 2 inches. Roof tile must be clean and dry. Air temperature should be at least 40°F.



STEP 1

Center TileSeal™ on top of roof nailing board. Staple or nail the TileSeal™ every 12 inches down hip or ridge nailing board.



STEP 2

Form the TileSeal™ to the tile roof surface. Install the TileSeal™ from the top of the hip to the eave.



STEP 3

Remove protective strip from adhesive tape.



STEP 4

Press TileSeal™ in pans of each tile. TileSeal™ can elongate 30% from barrel to pan. Take care that the edge area of the TileSeal™ is thoroughly pressed to tile. The corrugation of the TileSeal™ should become flat as the material is pressed into the tile. Then use a required rubber roller for adhesion.



STEP 5

Cut off the excess amount of the TileSeal™ at the end of the hip or ridge with a knife or sheet metal shears. The excess material can be used on the next project.



The perforations and edge of TileSeal™ are extremely sharp. Please wear gloves to eliminate the possibility of cuts and scrapes.

1657 South 580 East
American Fork, UT 84003